

DC CEILING FAN WALL CONTROL INSTALLATION AND OPERATION INSTRUCTION

READ AND SAVE THESE INSTRUCTIONS

Please read and understand this entire manual before attempting to install or operate the product. Make sure that all electrical connections comply with local codes, ordinances and the National Electrical Code. If you are unfamiliar with proper electrical wiring connections, obtain the services of a qualified electrician.

WARNING: Before proceeding, be sure to shut off electricity at main switch or circuit breaker in order to avoid electrical shock.

NOTE: Fan installation must be complete including assembly of blades before testing wall control unit.


Refer to your Ceiling fan instruction manual for safety and installation instructions.

This wall controller is to be used for the control of DC ceiling fan and fan light only, and in an AC120V 60Hz power supply only. WCD Wall Control must be installed with included Canopy Mounted Driver to operate properly.

IMPORTANT : Before installing the wall control, place it in OFF position by pushing ON/OFF switch to OFF.

Make wiring connections with wire nuts as shown in Fig.1.

- Connect fan motor wire to the driver : Red wire -Red wire, Grey wire - Grey wire, Pink wire - Orange wire, Yellow/green wire -Yellow/green wire.
- Connect the Light (White) wire(N) from the fan with the driver white wire (N) and Wall controller (TO MOTOR N) White wire together.
- Connect the Light (Blue) wire(L) from the fan to the Wall controller (FOR LIGHT) Blue wire.
- Connect the Black wire (AC IN L) from wall controller to the Live (Black wire) from house.
- Connect the White wire (AC IN N) from wall controller to the Neutra (White wire) from house.
- Connect the driver yellow/green grounded wire to grounded wire from outlet box.



Risk Of Electric Shock

- SHUT OFF POWER AT FUSE BOX OR CIRCUIT BREAKER BEFORE INSTALLATION.
- Install the wall controller unit to outlet box using machine screws.
- Attach wall plate press down to wall control as shown in Fig.2.






Figure 2

Wall Control Operation

The buttons on the wall controller control the fan speed and light as follows.



Press the FAN ON button to turn the fan power on.
 Press the OFF button to turn the fan and light power off.
 Press the FAN & LIGHT ON button to turn the fan and light power on.



Press the SPEED button to control the fan.

- 1- Highest Speed, No.1 light will be on
- 2- High Speed, No.2 light will be on
- 3- Med Speed, No.3 light will be on
- 4- Low Speed, No.4 light will be on
- 5- Lowest Speed, No.5 light will be on
- 0- Fan off, indicator light will be off



Forward/ Reverse-

Press this button to get desired airflow direction.

It will take a few seconds for fan to slow down and change rotation direction.