

4" LED RETROFIT INSTALLATION INSTRUCTIONS

IMPORTANT :

1. For your safety read and understand instructions completely before starting installation.
2. These luminaires (fixtures) are designed to meet the latest NEC requirements and are listed in full compliance with UL 1598.
3. Before attempting installation, check your local electrical code, as it sets the wiring standards for your locality.

⚠ WARNING - Risk of fire or electric shock.


1. Installation of this retrofit assembly requires a person familiar with the construction and operation of the luminaire's electrical system and the hazard involved. If not qualified, do not attempt installation. Contact qualified electrician.
2. Install this kit only in luminaires that have the construction features and dimensions described in these instructions, and where the input rating of the retrofit kit does not exceed the input rating of the luminaire.
3. LED Retrofit Kit installation requires knowledge of luminaire electrical systems. If not qualified, do not attempt installation. Contact a qualified electrician.
4. Luminaires wiring, power supply, or other electrical parts may be damaged when drilling for installation of retrofit assembly hardware. Inspect wiring and components for damage.

- **WARNING - To prevent wiring damage or abrasion, do not expose wiring to edges of sheet metal or other sharp objects.**
- **Do not make or alter any open holes in an enclosure of wiring or electrical components during kit installation.**
- **This device is not intended for use with emergency exits or not for emergency lighting.**

THE RETROFIT KIT IS ACCEPTED AS A COMPONENT OF A LUMINAIRE WHERE THE SUITABILITY OF THE COMBINATION SHALL BE DETERMINED BY CSA OR AUTHORITIES HAVING JURISDICTION.

INSTALLATION INTO RECESSED HOUSING WITH QUICK CONNECTOR

1. Plug the female connector of the retrofit-kit onto the male connector of the housing. (Fig. 1)
2. Squeeze the torsion springs together as shown and install into torsion spring brackets inside the housing. (Fig. 2)



INSTALLATION INTO EXISTING HOUSINGS WITH E26 BASE SOCKETS

1. Remove wing nut and socket bracket from inside existing housing.
2. Remove socket from socket bracket.
3. Screw E26 socket adapter into socket in housing. (Fig. 3)
4. Plug the female connector of the retrofit-kit onto the male connector of the socket adapter assembly. (Fig. 3)
5. Squeeze the spring clips together as shown and install into the housing. (Fig. 3)
6. Tuck all wires into the housing and carefully push the retrofit-kit into housing. (Fig. 4)




Figure 2




Figure 3

